

SONY 4-548-971-41(1)

Because BLUETOOTH devices and Wi-Fi (IEEE802.11b/g/n) use the same frequency (2.4 GHz), microwave interference may occur resulting in noise or audio dropout or communications problems. Use the following steps to avoid a Wi-Fi device. In such a case, perform the following.

- Use this unit at least 10 m away from the Wi-Fi device.
- If the unit is used within 10 m of a Wi-Fi device, turn off the Wi-Fi device.
- Install this unit and the BLUETOOTH device as near to each other as possible.
- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic media devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
 - where inflammable gas is present, in a hospital, or a petrol station
 - in a motor-vehicle or a fire alarm
- Do not use the unit on an airplane.
- Radio waves may affect instruments, causing an accident due to malfunction.
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the Bluetooth pairing technology is used, but its security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
- Do not use the unit for the leakage of information during BLUETOOTH communications.
- Connection with all BLUETOOTH devices cannot be guaranteed.

- A device featuring BLUETOOTH function is required to conform to the BLUETOOTH standard specified by Bluetooth SIG, Inc. and be authorized by them.
 - Even if the connected device conforms to the above mentioned BLUETOOTH standard, some devices may not be connected or work correctly, depending on the features or specifications of the device.
 - While talking on the phone hands free, noise may occur, depending on the device or communication environment.
- Depending on the device to be connected, it may require some time to start communication.

- This unit can be charged using USB only. Personal computer with USB port is not required for charging.
- This unit cannot be turned on, nor can the BLUETOOTH function be used, during charging.
- If you do not use the unit for a long time, the rechargeable battery may not be able to keep sufficient charge. The battery will be able to keep a charge properly after a complete discharge and charging several times.
- If you store the unit for a long time, charge the battery once every half year to prevent over-discharge.
- The length of time you can use the unit became extremely short, the rechargeable battery should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.

- Note on static electricity**
 - Static electricity accumulated in the body may cause mild tingling in your ears. To minimize the effect, wear clothes made of natural fibers.

- If the unit does not operate properly**
 - Reset the unit (Fig. B).
 - Push the RESET button with a pointed object, such as a pin, until you feel a click. The time will be reset. Pairing information is not deleted.
 - If the problem persists even after the resetting operation above, initialize the unit.
 - Push the RESET button with a pointed object, such as a pin, for more than 15 seconds. The indicator (blue flash) flashes 4 times, and the unit is reset to the factory settings. All pairing information is deleted.
 - After the unit is initialized, it may not connect to your iPhone or computer. In this case, delete the pairing information of the unit from the iPhone or computer, and then pair them again.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Because BLUETOOTH devices and Wi-Fi (IEEE802.11b/g/n) use the same frequency (2.4 GHz), microwave interference may occur resulting in noise or audio dropout or communications problems. Use the following steps to avoid a Wi-Fi device. In such a case, perform the following.

- Use this unit at least 10 m away from the Wi-Fi device.
- If the unit is used within 10 m of a Wi-Fi device, turn off the Wi-Fi device.
- Install this unit and the BLUETOOTH device as near to each other as possible.
- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic media devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
 - where inflammable gas is present, in a hospital, or a petrol station
 - in a motor-vehicle or a fire alarm
- Do not use the unit on an airplane.
- Radio waves may affect instruments, causing an accident due to malfunction.
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the Bluetooth pairing technology is used, but its security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
- Do not use the unit for the leakage of information during BLUETOOTH communications.
- Connection with all BLUETOOTH devices cannot be guaranteed.

- A device featuring BLUETOOTH function is required to conform to the BLUETOOTH standard specified by Bluetooth SIG, Inc. and be authorized by them.
 - Even if the connected device conforms to the above mentioned BLUETOOTH standard, some devices may not be connected or work correctly, depending on the features or specifications of the device.
 - While talking on the phone hands free, noise may occur, depending on the device or communication environment.
- Depending on the device to be connected, it may require some time to start communication.

- This unit can be charged using USB only. Personal computer with USB port is not required for charging.
- This unit cannot be turned on, nor can the BLUETOOTH function be used, during charging.
- If you do not use the unit for a long time, the rechargeable battery may not be able to keep sufficient charge. The battery will be able to keep a charge properly after a complete discharge and charging several times.
- If you store the unit for a long time, charge the battery once every half year to prevent over-discharge.
- The length of time you can use the unit became extremely short, the rechargeable battery should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.

- Note on static electricity**
 - Static electricity accumulated in the body may cause mild tingling in your ears. To minimize the effect, wear clothes made of natural fibers.

- If the unit does not operate properly**
 - Reset the unit (Fig. B).
 - Push the RESET button with a pointed object, such as a pin, until you feel a click. The time will be reset. Pairing information is not deleted.
 - If the problem persists even after the resetting operation above, initialize the unit.
 - Push the RESET button with a pointed object, such as a pin, for more than 15 seconds. The indicator (blue flash) flashes 4 times, and the unit is reset to the factory settings. All pairing information is deleted.
 - After the unit is initialized, it may not connect to your iPhone or computer. In this case, delete the pairing information of the unit from the iPhone or computer, and then pair them again.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan.
Detailed information regarding the environmental and human health legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

Charging time:
Note: Charging hours may be different depending on the conditions of use.
Charging temperature: 5 °C to 35 °C

Receiver
Type: Closed, Dynamic
Driver units: 9 mm
Frequency response: 20 Hz - 20,000 Hz

Microphone
Type: Electret condenser
Directivity: Omni-directional
Effective frequency range: 100 Hz - 4,000 Hz

System requirements for battery charge using USB
Personal Computer with pre-installed with any of the following operating systems and USB port:

Operating Systems
(when using Windows)
Windows® 8.1 / Windows® 8 Pro
Windows® 7 / Windows® 8 Pro
Windows® 7

Home Basic / Home Premium / Professional / Ultimate
Windows Vista® (Service Pack 2 or later)
Home Basic / Home Premium / Business / Ultimate
(when using Mac)
Mac OS X (version 10.3 or later)

Design and specifications are subject to change without notice.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

AVERTISSEMENT

Pour éviter tout risque d'électrochoc, n'ouvrez pas le couvercle. Ne contactez les réparations qu'à un technicien qualifié.

N'installez pas l'appareil dans un espace restreint, comme une bibliothèque ou un meuble encastré.
N'exposez pas les piles (piles rechargeables ou installées) à une chaleur excessive et ne les laissez pas se réchauffer. Évitez d'autres sources de chaleur pendant une période prolongée.
Avis à l'intention des clients : les informations suivantes s'appliquent uniquement aux appareils vendus dans des pays qui appliquent les directives de l'Union Européenne

Le produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For your question relative to the Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents - Service (SAV) ou Garantie.

Français

Si vous n'utilisez pas l'appareil pendant une période de temps prolongée, la batterie rechargeable risque de ne pas garder une charge suffisante. La batterie pourra garder une charge correcte après l'avoir déchargée et chargée à maintes reprises.

Si vous rangez l'appareil pendant une période de temps prolongée, chargez la batterie deux fois par an pour éviter la décharge totale.

Si la durée d'utilisation de l'appareil devient courte, vous devez recharger la batterie rechargeable par une nouvelle. Veuillez contacter votre revendeur Sony le plus proche afin de remplacer la batterie.

Remarque sur l'électricité statique

L'électricité statique accumulée dans le boîtier peut entraîner de légers picotements au niveau des oreilles. Pour en réduire les effets, portez des vêtements en fibres naturelles.

Si l'appareil ne fonctionne pas correctement

Initialisez l'appareil (Fig. B).
Appuyez sur le bouton RESET avec un objet pointu, comme une épingle, jusqu'à ce que vous sentiez un clic. L'appareil est réinitialisé. Les informations sur le pairing ne sont pas supprimées.

Si le problème persiste même après avoir effectué l'opération de réinitialisation ci-dessus, initialisez l'appareil comme suit. Appuyez sur le bouton RESET avec un objet pointu, comme une épingle, pendant plus de 15 secondes. Le témoin (bleu) clignote 4 fois et l'appareil est réinitialisé selon les normes réglementaires définies dans l'eau. Sauf si vous utilisez le pairing soit supprimées.

Après avoir initialisé l'appareil, il se peut qu'il ne se connecte pas à votre iPhone ou à votre ordinateur. Dans ce cas, supprimez les informations de pairing de l'appareil sur l'iPhone ou l'ordinateur, puis appariez-les de nouveau.

Performances anti-éclaboussures

Les spécifications anti-éclaboussures* de cet appareil sont applicables à l'IPX4 dans la norme IEC 60529 « Degré de protection contre la pénétration d'eau (code IP) », qui spécifie le degré de protection fourni contre l'entrée d'eau. Toutefois, si vous utilisez l'appareil sous l'eau, toutes les précautions suivantes et utilisez l'appareil correctement.

Liquides concernés par les spécifications anti-éclaboussures

Conteneurs : vinaigre, eau du robinet, transpiration
Non concernés : liquides corrosifs (exemples : eau savonneuse, eau contenant du détergent, eau avec adjuvants de bain, shampooing, eau de source chaude, eau de piscine, eau de mer, etc.)

1 Assurez-vous que le couvercle du port micro-USB est bien fermé lorsque vous utilisez l'appareil.
2 IPX4 (degré de protection contre les éclaboussures d'eau) : protégé contre les éclaboussures d'eau provenant de toutes directions.

Les performances anti-éclaboussures de l'appareil sont basées sur les mesures de Sony dans les conditions décrites ci-dessus. Toutefois, les dysfonctionnements liés à une mauvaise utilisation peuvent ne pas être maintenus. En outre, l'utilisation du client ne sont pas couverts par la garantie.

Pour maintenir les performances anti-éclaboussures
Notez soigneusement les précautions suivantes et utilisez l'appareil correctement.

1 Ne touchez pas l'appareil, ni l'exposez pas à un choc mécanique. Cela pourrait déformer ou endommager l'appareil, ce qui entraîne la détérioration des performances anti-éclaboussures.

2 Ne mettez pas l'appareil dans l'eau, ni l'utilisez pas dans un endroit humide, tel qu'une salle de bain.

3 Assurez-vous que le couvercle du port micro-USB est bien fermé lorsque vous utilisez l'appareil. Si des objets étrangers se trouvent sur le capot, ou si ce dernier n'est pas complètement fermé, les performances anti-éclaboussures peuvent ne pas être maintenues. En outre, l'utilisation de l'eau peut pénétrer dans l'appareil et entraîner un dysfonctionnement.

4 Essayez avec un chiffon doux et sec l'eau se trouvant sur l'appareil. Si l'eau s'infiltre dans les trous des oreillettes, le son peut sembler bas ou ne pas être audible du tout. Dans ce cas, retirez les oreillettes, placez le conduit sonore sur une surface appropriée, vous partirez avec un chiffon doux et sec, retirez l'appareil recouvert d'eau dans des endroits secs et laissez sécher complètement pendant 24 heures.

5 Assurez-vous que le couvercle du port micro-USB est bien fermé lorsque vous utilisez l'appareil. Si des objets étrangers se trouvent sur le capot, ou si ce dernier n'est pas complètement fermé, les performances anti-éclaboussures peuvent ne pas être maintenues. En outre, l'utilisation de l'eau peut pénétrer dans l'appareil et entraîner un dysfonctionnement.

6 Essayez avec un chiffon doux et sec l'eau se trouvant sur l'appareil. Si l'eau s'infiltre dans les trous des oreillettes, le son peut sembler bas ou ne pas être audible du tout. Dans ce cas, retirez les oreillettes, placez le conduit sonore sur une surface appropriée, vous partirez avec un chiffon doux et sec, retirez l'appareil recouvert d'eau dans des endroits secs et laissez sécher complètement pendant 24 heures.

7 Assurez-vous que le couvercle du port micro-USB est bien fermé lorsque vous utilisez l'appareil. Si des objets étrangers se trouvent sur le capot, ou si ce dernier n'est pas complètement fermé, les performances anti-éclaboussures peuvent ne pas être maintenues. En outre, l'utilisation de l'eau peut pénétrer dans l'appareil et entraîner un dysfonctionnement.

8 Essayez avec un chiffon doux et sec l'eau se trouvant sur l'appareil. Si l'eau s'infiltre dans les trous des oreillettes, le son peut sembler bas ou ne pas être audible du tout. Dans ce cas, retirez les oreillettes, placez le conduit sonore sur une surface appropriée, vous partirez avec un chiffon doux et sec, retirez l'appareil recouvert d'eau dans des endroits secs et laissez sécher complètement pendant 24 heures

