

English

Before operating the system, please read this manual thoroughly and retain it for future reference.

WARNING

To prevent fire or shock hazard, do not expose the system to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Features

The Sony SRS-PC51 is a compact-size speaker system with a built-in power amplifier designed for the use with a computer. A Discman, WALKMAN®, etc. can be connected to this system as well.

- The magnetically shielded speakers have little effect on a PC monitor or recorded tapes, etc. when placed close to them.
- Easy installation on both sides of a PC monitor with the supplied mounting brackets.
- Equipped with a headphones jack.
- Power output of 2.5 W + 2.5 W.
- IBB (Intelligent Bass Boost) circuit enable you to obtain powerful bass, regardless of the sound volume.

* WALKMAN is a registered trademark of Sony Corporation.

Precautions

- Use only the supplied AC power adaptor for operating the system. Do not use any other AC power adaptors.
- After operating the system with the AC power adaptor, disconnect the AC power adaptor from the wall outlet if the system is not to be used for an extended period of time. The POWER switch on the left speaker does not turn the AC power adaptor off.
- Do not open the speaker cabinets. Refer servicing to qualified personnel only.
- Do not leave the system in a location near heat sources, or in a place subject to direct sunlight, excessive dust, moisture, rain or mechanical shock.
- Should any solid object or liquid fall into either speaker, disconnect the AC power adaptor and have the speaker checked by qualified personnel before operating it any further.
- When the speaker cabinet becomes soiled, clean it with a soft cloth slightly moistened with a mild detergent solution. Never use alcohol, benzine or thinner as they may mar the finish.
- Although this system is magnetically shielded, as a precaution, do not leave recorded tapes, watches, personal credit cards or floppy disks using magnetic coding in front of the system for an extended period of time.

If the TV picture or monitor display is magnetically distorted

Although this system is magnetically shielded, there may be cases that the picture on some TV sets/personal computer sets may become magnetically distorted. In such a case, turn off the power of the TV set/personal computer set once, and after 15 to 30 minutes turn it on again. For the personal computer set, take the appropriate measures such as data storage before turning it off. When there seems to be no improvement, locate the system further away from the TV set/personal computer set. Furthermore, be sure not to place objects in which magnets are attached or used near the TV set/personal computer set, such as audio racks, TV stands, toys etc. These may cause magnetic distortion to the picture due to their interaction with the system.

If you have any questions or problems concerning your system that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

Amplifier section	
Power output	2.5 W + 2.5 W
Input	Input cord (stereo mini plug (2 m)), stereo mini jack
Input impedance	4.7 kilohm (at 1 kHz)
Speaker section	
System	Full-range bass reflex type
Speaker unit	Full-range (magnetically shielded): ø 57 mm (2 1/4 in.)
Normal impedance	3.2 ohm
Rated input power	2.5 W
General	
Power requirement	DC IN 9V jack accepts the supplied Sony AC power adaptor
Dimensions	Approx. 80 x 206 x 146 mm (3 1/4 x 8 1/4 x 5 7/8 in.) (w/h/d) incl. projecting parts and controls
Mass	Approx. 400 g (14 oz) (left speaker)
Supplied accessories	Approx. 350 g (12 oz) (right speaker) <p>AC power adaptor (1)</p> <p>Mounting brackets (2)</p> <p>Stands (2)</p> <p>Rubber cushions (2)</p> <p>Double-sided tapes (4)</p> <p>Screws (2)</p>
Optional accessories	Plug adaptor PC-234HG, PC-236HG <p>Connecting cord RR-G138HG, RR-G138HG</p>

Your dealer may not handle some of the above listed optional accessories. Please ask the dealer for detailed information.

Design and specifications are subject to change without notice.

The CE mark on the unit is valid only for products marketed in the European Union.

Po

Before operating the system, please read this manual thoroughly and retain it for future reference.

WARNING

To prevent fire or shock hazard, do not expose the system to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Features

The Sony SRS-PC51 is a compact-size speaker system with a built-in power amplifier designed for the use with a computer. A Discman, WALKMAN®, etc. can be connected to this system as well.

- The magnetically shielded speakers have little effect on a PC monitor or recorded tapes, etc. when placed close to them.
- Easy installation on both sides of a PC monitor with the supplied mounting brackets.
- Equipped with a headphones jack.
- Power output of 2.5 W + 2.5 W.
- IBB (Intelligent Bass Boost) circuit enable you to obtain powerful bass, regardless of the sound volume.

* WALKMAN is a registered trademark of Sony Corporation.

Precautions

- Use only the supplied AC power adaptor for operating the system. Do not use any other AC power adaptors.
- After operating the system with the AC power adaptor, disconnect the AC power adaptor from the wall outlet if the system is not to be used for an extended period of time. The POWER switch on the left speaker does not turn the AC power adaptor off.
- Do not open the speaker cabinets. Refer servicing to qualified personnel only.
- Do not leave the system in a location near heat sources, or in a place subject to direct sunlight, excessive dust, moisture, rain or mechanical shock.
- Should any solid object or liquid fall into either speaker, disconnect the AC power adaptor and have the speaker checked by qualified personnel before operating it any further.
- When the speaker cabinet becomes soiled, clean it with a soft cloth slightly moistened with a mild detergent solution. Never use alcohol, benzine or thinner as they may mar the finish.
- Although this system is magnetically shielded, as a precaution, do not leave recorded tapes, watches, personal credit cards or floppy disks using magnetic coding in front of the system for an extended period of time.

If the TV picture or monitor display is magnetically distorted

Although this system is magnetically shielded, there may be cases that the picture on some TV sets/personal computer sets may become magnetically distorted. In such a case, turn off the power of the TV set/personal computer set once, and after 15 to 30 minutes turn it on again. For the personal computer set, take the appropriate measures such as data storage before turning it off. When there seems to be no improvement, locate the system further away from the TV set/personal computer set. Furthermore, be sure not to place objects in which magnets are attached or used near the TV set/personal computer set, such as audio racks, TV stands, toys etc. These may cause magnetic distortion to the picture due to their interaction with the system.

If you have any questions or problems concerning your system that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

Amplifier section	
Power output	2.5 W + 2.5 W
Input	Input cord (stereo mini plug (2 m)), stereo mini jack
Input impedance	4.7 kilohm (at 1 kHz)
Speaker section	
System	Full-range bass reflex type
Speaker unit	Full-range (magnetically shielded): ø 57 mm (2 1/4 in.)
Normal impedance	3.2 ohm
Rated input power	2.5 W
General	
Power requirement	DC IN 9V jack accepts the supplied Sony AC power adaptor
Dimensions	Approx. 80 x 206 x 146 mm (3 1/4 x 8 1/4 x 5 7/8 in.) (w/h/d) incl. projecting parts and controls
Mass	Approx. 400 g (14 oz) (left speaker)
Supplied accessories	Approx. 350 g (12 oz) (right speaker) <p>AC power adaptor (1)</p> <p>Mounting brackets (2)</p> <p>Stands (2)</p> <p>Rubber cushions (2)</p> <p>Double-sided tapes (4)</p> <p>Screws (2)</p>
Optional accessories	Plug adaptor PC-234HG, PC-236HG <p>Connecting cord RR-G138HG, RR-G138HG</p>

Your dealer may not handle some of the above listed optional accessories. Please ask the dealer for detailed information.

Design and specifications are subject to change without notice.

The CE mark on the unit is valid only for products marketed in the European Union.

Ru

Before operating the system, please read this manual thoroughly and retain it for future reference.

WARNING

To prevent fire or shock hazard, do not expose the system to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Features

The Sony SRS-PC51 is a compact-size speaker system with a built-in power amplifier designed for the use with a computer. A Discman, WALKMAN®, etc. can be connected to this system as well.

- The magnetically shielded speakers have little effect on a PC monitor or recorded tapes, etc. when placed close to them.
- Easy installation on both sides of a PC monitor with the supplied mounting brackets.
- Equipped with a headphones jack.
- Power output of 2.5 W + 2.5 W.
- IBB (Intelligent Bass Boost) circuit enable you to obtain powerful bass, regardless of the sound volume.

* WALKMAN is a registered trademark of Sony Corporation.

Precautions

- Use only the supplied AC power adaptor for operating the system. Do not use any other AC power adaptors.
- After operating the system with the AC power adaptor, disconnect the AC power adaptor from the wall outlet if the system is not to be used for an extended period of time. The POWER switch on the left speaker does not turn the AC power adaptor off.
- Do not open the speaker cabinets. Refer servicing to qualified personnel only.
- Do not leave the system in a location near heat sources, or in a place subject to direct sunlight, excessive dust, moisture, rain or mechanical shock.
- Should any solid object or liquid fall into either speaker, disconnect the AC power adaptor and have the speaker checked by qualified personnel before operating it any further.
- When the speaker cabinet becomes soiled, clean it with a soft cloth slightly moistened with a mild detergent solution. Never use alcohol, benzine or thinner as they may mar the finish.
- Although this system is magnetically shielded, as a precaution, do not leave recorded tapes, watches, personal credit cards or floppy disks using magnetic coding in front of the system for an extended period of time.

If the TV picture or monitor display is magnetically distorted

Although this system is magnetically shielded, there may be cases that the picture on some TV sets/personal computer sets may become magnetically distorted. In such a case, turn off the power of the TV set/personal computer set once, and after 15 to 30 minutes turn it on again. For the personal computer set, take the appropriate measures such as data storage before turning it off. When there seems to be no improvement, locate the system further away from the TV set/personal computer set. Furthermore, be sure not to place objects in which magnets are attached or used near the TV set/personal computer set, such as audio racks, TV stands, toys etc. These may cause magnetic distortion to the picture due to their interaction with the system.

If you have any questions or problems concerning your system that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

Amplifier section	
Power output	2.5 W + 2.5 W
Input	Input cord (stereo mini plug (2 m)), stereo mini jack
Input impedance	4.7 kilohm (at 1 kHz)
Speaker section	
System	Full-range bass reflex type
Speaker unit	Full-range (magnetically shielded): ø 57 mm (2 1/4 in.)
Normal impedance	3.2 ohm
Rated input power	2.5 W
General	
Power requirement	DC IN 9V jack accepts the supplied Sony AC power adaptor
Dimensions	Approx. 80 x 206 x 146 mm (3 1/4 x 8 1/4 x 5 7/8 in.) (w/h/d) incl. projecting parts and controls
Mass	Approx. 400 g (14 oz) (left speaker)
Supplied accessories	Approx. 350 g (12 oz) (right speaker) <p>AC power adaptor (1)</p> <p>Mounting brackets (2)</p> <p>Stands (2)</p> <p>Rubber cushions (2)</p> <p>Double-sided tapes (4)</p> <p>Screws (2)</p>
Optional accessories	Plug adaptor PC-234HG, PC-236HG <p>Connecting cord RR-G138HG, RR-G138HG</p>

Your dealer may not handle some of the above listed optional accessories. Please ask the dealer for detailed information.

Design and specifications are subject to change without notice.

The CE mark on the unit is valid only for products marketed in the European Union.

Cz

Before operating the system, please read this manual thoroughly and retain it for future reference.

WARNING

To prevent fire or shock hazard, do not expose the system to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Features

The Sony SRS-PC51 is a compact-size speaker system with a built-in power amplifier designed for the use with a computer. A Discman, WALKMAN®, etc. can be connected to this system as well.

- The magnetically shielded speakers have little effect on a PC monitor or recorded tapes, etc. when placed close to them.
- Easy installation on both sides of a PC monitor with the supplied mounting brackets.
- Equipped with a headphones jack.
- Power output of 2.5 W + 2.5 W.
- IBB (Intelligent Bass Boost) circuit enable you to obtain powerful bass, regardless of the sound volume.

* WALKMAN is a registered trademark of Sony Corporation.

Precautions

- Use only the supplied AC power adaptor for operating the system. Do not use any other AC power adaptors.
- After operating the system with the AC power adaptor, disconnect the AC power adaptor from the wall outlet if the system is not to be used for an extended period of time. The POWER switch on the left speaker does not turn the AC power adaptor off.
- Do not open the speaker cabinets. Refer servicing to qualified personnel only.
- Do not leave the system in a location near heat sources, or in a place subject to direct sunlight, excessive dust, moisture, rain or mechanical shock.
- Should any solid object or liquid fall into either speaker, disconnect the AC power adaptor and have the speaker checked by qualified personnel before operating it any further.
- When the speaker cabinet becomes soiled, clean it with a soft cloth slightly moistened with a mild detergent solution. Never use alcohol, benzine or thinner as they may mar the finish.
- Although this system is magnetically shielded, as a precaution, do not leave recorded tapes, watches, personal credit cards or floppy disks using magnetic coding in front of the system for an extended period of time.

If the TV picture or monitor display is magnetically distorted

Although this system is magnetically shielded, there may be cases that the picture on some TV sets/personal computer sets may become magnetically distorted. In such a case, turn off the power of the TV set/personal computer set once, and after 15 to 30 minutes turn it on again. For the personal computer set, take the appropriate measures such as data storage before turning it off. When there seems to be no improvement, locate the system further away from the TV set/personal computer set. Furthermore, be sure not to place objects in which magnets are attached or used near the TV set/personal computer set, such as audio racks, TV stands, toys etc. These may cause magnetic distortion to the picture due to their interaction with the system.

If you have any questions or problems concerning your system that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

Amplifier section	
Power output	2.5 W + 2.5 W
Input	Input cord (stereo mini plug (2 m)), stereo mini jack
Input impedance	4.7 kilohm (at 1 kHz)
Speaker section	
System	Full-range bass reflex type
Speaker unit	Full-range (magnetically shielded): ø 57 mm (2 1/4 in.)
Normal impedance	3.2 ohm
Rated input power	2.5 W
General	
Power requirement	DC IN 9V jack accepts the supplied Sony AC power adaptor
Dimensions	Approx. 80 x 206 x 146 mm (3 1/4 x 8 1/4 x 5 7/8 in.) (w/h/d) incl. projecting parts and controls
Mass	Approx. 400 g (14 oz) (left speaker)
Supplied accessories	Approx. 350 g (12 oz) (right speaker) <p>AC power adaptor (1)</p> <p>Mounting brackets (2)</p> <p>Stands (2)</p> <p>Rubber cushions (2)</p> <p>Double-sided tapes (4)</p> <p>Screws (2)</p>
Optional accessories	Plug adaptor PC-234HG, PC-236HG <p>Connecting cord RR-G138HG, RR-G138HG</p>

Your dealer may not handle some of the above listed optional accessories. Please ask the dealer for detailed information.

Design and specifications are subject to change without notice.

The CE mark on the unit is valid only for products marketed in the European Union.

Hn

Before operating the system, please read this manual thoroughly and retain it for future reference.

WARNING

To prevent fire or shock hazard, do not expose the system to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Features

The Sony SRS-PC51 is a compact-size speaker system with a built-in power amplifier designed for the use with a computer. A Discman, WALKMAN®, etc. can be connected to this system as well.

- The magnetically shielded speakers have little effect on a PC monitor or recorded tapes, etc. when placed close to them.
- Easy installation on both sides of a PC monitor with the supplied mounting brackets.
- Equipped with a headphones jack.
- Power output of 2.5 W + 2.5 W.
- IBB (Intelligent Bass Boost) circuit enable you to obtain powerful bass, regardless of the sound volume.

* WALKMAN is a registered trademark of Sony Corporation.

Precautions

- Use only the supplied AC power adaptor for operating the system. Do not use any other AC power adaptors.
- After operating the system with the AC power adaptor, disconnect the AC power adaptor from the wall outlet if the system is not to be used for an extended period of time. The POWER switch on the left speaker does not turn the AC power adaptor off.
- Do not open the speaker cabinets. Refer servicing to qualified personnel only.
- Do not leave the system in a location near heat sources, or in a place subject to direct sunlight, excessive dust, moisture, rain or mechanical shock.
- Should any solid object or liquid fall into either speaker, disconnect the AC power adaptor and have the speaker checked by qualified personnel before operating it any further.
- When the speaker cabinet becomes soiled, clean it with a soft cloth slightly moistened with a mild detergent solution. Never use alcohol, benzine or thinner as they may mar the finish.
- Although this system is magnetically shielded, as a precaution, do not leave recorded tapes, watches, personal credit cards or floppy disks using magnetic coding in front of the system for an extended period of time.

If the TV picture or monitor display is magnetically distorted

Although this system is magnetically shielded, there may be cases that the picture on some TV sets/personal computer sets may become magnetically distorted. In such a case, turn off the power of the TV set/personal computer set once, and after 15 to 30 minutes turn it on again. For the personal computer set, take the appropriate measures such as data storage before turning it off. When there seems to be no improvement, locate the system further away from the TV set/personal computer set. Furthermore, be sure not to place objects in which magnets are attached or used near the TV set/personal computer set, such as audio racks, TV stands, toys etc. These may cause magnetic distortion to the picture due to their interaction with the system.

If you have any questions or problems concerning your system that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

Amplifier section	
Power output	2.5 W + 2.5 W
Input	Input cord (stereo mini plug (2 m)), stereo mini jack
Input impedance	4.7 kilohm (at 1 kHz)
Speaker section	
System	Full-range bass reflex type
Speaker unit	Full-range (magnetically shielded): ø 57 mm (2 1/4 in.)
Normal impedance	3.2 ohm
Rated input power	2.5 W
General	
Power requirement	DC IN 9V jack accepts the supplied Sony AC power adaptor
Dimensions	Approx. 80 x 206 x 146 mm (3 1/4 x 8 1/4 x 5 7/8 in.) (w/h/d) incl. projecting parts and controls
Mass	Approx. 400 g (14 oz) (left speaker)
Supplied accessories	Approx. 350 g (12 oz) (right speaker) <p>AC power adaptor (1)</p> <p>Mounting brackets (2)</p> <p>Stands (2)</p> <p>Rubber cushions (2)</p> <p>Double-sided tapes (4)</p> <p>Screws (2)</p>
Optional accessories	Plug adaptor PC-234HG, PC-236HG <p>Connecting cord RR-G138HG, RR-G138HG</p>

Your dealer may not handle some of the above listed optional accessories. Please ask the dealer for detailed information.

Design and specifications are subject to change without notice.

The CE mark on the unit is valid only for products marketed in the European Union.

Stereo Active Speaker System

Operating Instructions

Po

Ro

Cz

Hn

SRS-PC51

Sony Corporation © 1998 Printed in Philippines



