






1





2










3



NW-WS623





Windows

Music Center for PC
<http://www.sony.net/smc4pc/>

Mac

Content Transfer for Mac
<http://www.sony.net/ct-mac/>

http://rd1.sony.net/help/dmp/nwws620/h_ww/